

INSTALLATION & USER GUIDE



For Precise Volume

Adjustment

in Any Room

12-STEP WALL MOUNT VOLUME CONTROL

V-12

V-12

12-STEP WALL MOUNT VOLUME CONTROL

TABLE OF CONTENTS

Features.....	1
Product Overview.....	2
Package Contents	3
Preparing for Installation.....	3
Installation.....	4
Operation.....	6
Specifications.....	7
Warranty.....	7

FEATURES


- Includes both Decora® style and standard faceplates
- Safely connect up to eight speaker pairs to a single amplifier or receiver
- UL listed to comply with local building codes
- Stylish indicator knob
- 12-step make before break volume control switch design

Installation friendly design:

- Snap and lock connector secures wire in place without the use of a screwdriver



PRODUCT OVERVIEW



PACKAGE CONTENTS

- V-12 Volume control x 1
- Snap-on Decora® style color insert x 1
- Decora® style wall plate x 1
- Standard wall plate x 1
- Knob x 1
- Device mounting screws x 2
- Faceplate screws x 2
- Snap and lock removable speaker connectors x 2




Figure 2




Figure 3




Figure 4

Using Speaker Selectors with IM Volume Controls

Although IM controls provide volume and on/off at the volume-control location, they do not give you central control of speakers playing throughout the house. Speaker-selection systems give you central control, but some speaker selectors have non-defeatable impedance-protection circuits. Combining IM controls with such a selector will reduce your maximum volume substantially. To solve this problem, specify a speaker selector with a defeatable protection circuit (JobSite models S-4 or S-6). Then keep the protection circuit off at all times.

Tools Required

- 1/8" Slotted screwdriver
- 1/4" Slotted screwdriver
- No2 Phillips screwdriver
- Wire stripper
- Wire labels

4

INSTALLATION

1. Identify the speaker wire and amplifier wire. Label the wires for future reference.
2. Strip 1/4" of insulation from the end of each wire. Tightly twist the end of each wire until no frayed ends remain.
3. Locate the snap and lock connectors and remove them if they are plugged in. **See figure 5.**





Figure 5

4. Use a small flathead screwdriver or your thumb to raise the locking tabs, exposing the holes on the connector.
5. Insert each wire into the appropriate hole and snap down the locking tabs.
6. Insert the smooth side of the connector plug into the smooth side of the V-12 socket.
7. Install the V-12 into the device ring.
8. Set the Impedance Magnification Switch as determined by the impedance charts.
9. Set the switches, on all of the controls, to the same position (1x, 2x, 4x, or 8x).
10. Attach the cover plate.

See installation diagram.

INSTALLATION DIAGRAM



OPERATION

1. Make sure the amplifier or receiver power is OFF and set the volume to minimum.
2. Set the volume on the volume control to maximum (fully clockwise).
3. If you are using a JobSite speaker-selection system, locate the ON/OFF button that corresponds to the speaker pair you wish to play. Set it to the ON position. Make sure the defeatable protection circuit is not enabled. See Using Speaker Selectors with IM Volume Controls, **on page 4**.
4. Turn ON the amplifier or receiver and select a source, such as the Tuner or CD player.
5. Slowly turn up the amplifier or receiver volume and set it to a comfortable – not maximum – listening level. Don't overdrive or "clip" your amplifier. If the sound becomes muddy or distorted, you have reached the limit of your amplifier's volume capability. Reduce the volume at once to avoid damaging your speakers.
6. Use the volume control to adjust the volume of the speakers to the desired listening level. If all the speaker pairs in your system are equipped with JobSite volume controls, you can set the amplifier or receiver volume at one position and use the JobSite controls exclusively.
7. To turn OFF the speakers, turn the knob on the volume control fully counter-clockwise, or press the ON/OFF button on your speaker selector.

SPECIFICATIONS

High power rating:

100 watts per channel RMS, 200 watts peak

Adjustable impedance:

1x, 2x, 4x, 8x settings

Total attenuation:

54dB maximum

Wiring requirements:

2 individual runs of 2-conductor 14-18-gauge speaker wire or 1 run of 4 conductors

V-T8 volume control connection terminal recommended

Mounting:

Fits most single gang junction boxes

Dimensions:

1-5/8" wide x 2-5/8" high x 2-9/16" deep

Depth behind faceplate:

2-9/16"

Warranty: 10 year limited

LIMITED WARRANTY

JobSite Systems ("JOBSITE"), a Niles Audio Corporation company, warrants its passive products (those not requiring AC or battery power) to the original purchaser to be free of manufacturing defects in material and workmanship for a period of ten years from date of purchase.

JOBSITE warrants its passive loudspeaker products (those not requiring AC or battery power) to the original purchaser to be free of manufacturing defects in material and workmanship for a period of five years from date of purchase.

JOBSITE warrants its indoor/outdoor loudspeaker products to the original purchaser to be free of manufacturing defects in material and workmanship for a period of two years from date of purchase.

JOBSITE warrants its all weather rock loudspeaker products to the original purchaser to be free of manufacturing defects in material and workmanship for a period of five years from date of purchase. **7**

JOBSITE warrants its active products (those requiring AC or battery power) to the original purchaser to be free of manufacturing defects in material and workmanship for a period of two years from date of purchase.

This Warranty is subject to the following additional conditions and limitations. The Warranty is void and inapplicable if JOBSITE deems that the product has been used or handled other than in accordance with the instructions provided by the manufacturer, including, but not limited to, damage caused by accident, mishandling, improper installation, abuse, negligence, or normal wear and tear, or any defect caused by repair to the product other than by JOBSITE or an authorized JOBSITE wholesale distributor.

To obtain warranty service, you must write to JOBSITE: Include your name, address, telephone number, model number and serial number of your

unit, and a brief description of the problem. A factory Return Authorization Number will be sent to you. **DO NOT RETURN ANY UNIT WITHOUT FIRST RECEIVING WRITTEN AUTHORIZATION AND SHIPPING INSTRUCTIONS FROM JOBSITE.**

If the above conditions are met, the purchaser's sole remedy shall be to return the product to JOBSITE, in which case JOBSITE will repair or replace, at its sole option, the defective product without charge for parts or labor. JOBSITE will return the unit repaired or replaced under warranty by shipping it by its usual shipping method from the factory (only) at its expense within the United States of America. **THERE ARE NO OTHER WARRANTIES, INCLUDING, WITHOUT LIMITATION, EITHER EXPRESS OR IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, WITH RESPECT TO THE PRODUCT.**

REPAIR OR REPLACEMENT AS PROVIDED UNDER THIS WARRANTY IS THE EXCLUSIVE REMEDY OF THE CONSUMER/PURCHASER. NILES SHALL NOT BE RESPONSIBLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES EXCEPT TO THE EXTENT PROVIDED (OR PROHIBITED) BY APPLICABLE LAW.

Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation may not apply to you. This warranty gives you specific legal rights, and you may also have other rights, which vary from state to state.

For the name of the nearest authorized JOBSITE wholesale distributor, contact:

JobSite Systems

12331 S.W. 130 Street, Miami, Florida 33186

WWW.JOBSITESYSTEMS.COM



JOBSITE SYSTEMS

12331 S.W. 130 STREET, MIAMI, FLORIDA 33186

P 866.4JB.SITE (866.452.7483) – F 305.238.0185

WWW.JOBSITESYSTEMS.COM

© 2004 JobSite Systems. All rights reserved. JobSite, Pure Custom and Niles are registered trademarks of Niles Audio Corporation and the JobSite Logo is a trademark of Niles Audio Corporation. All other trademarks are the property of their respective owners. Some JobSite products (or components thereof) are manufactured under one or more U.S. Patents, foreign equivalents and/or pending patents (see product for details). Because we constantly strive to improve our products, JobSite reserves the right to change product specifications, descriptions, and prices without notice. The technical and other specifications of information contained herein are not intended to set forth all technical and other specifications of JobSite products. Additional information can be obtained at WWW.JOBSITESYSTEMS.COM or by calling JobSite at 866.452.7483. Printed in China. 2/05 DS00376BCN